

BADECO S.A.

Handpiece 295

Introducing and Releasing the Tools.

Spindle Ø has to be exactly the same as burr holder Ø. Spindle has to be very clean and smooth on its whole length. A spindle in bad condition can damage the handpiece.

Stop motor. Keep the holder in one hand while the other is turning the bush to the left. Push it forward and lock it turning it to the right (clockwise looking from back to front). The nut can then be unscrewed. After introducing the spindle, tighten the nut with your fingers and lock it with a 6 mm spanner. Turn the bush to the left and nut will move into place. It will lock automatically.

Important.

It is recommended to wear spectacles.
Never keep running when not in use.
Low speed will considerably lengthen the service life of the punch.

Maintenance and Lubrification.

You possess a precision tool which will have a long life span if you take care of it.

To lubricate.

Before every lubrication, unscrew and remove the nut and the burr holder. Plunge them into Petroleum or Benzine (caution toxic and inflammable !) Drain and dry them. Do not use a remover product ! Lubricate them as well as the thread and the inside of the axle (with a little bottle-brush). Burr holder and nut to be put back in place.

Repair.

Not dismantle !
Repair to be made at BADECO in Geneva works only to guarantee utmost performance and power.

Warranty.

Repairs caused by faulty material or workmanship will be rectified at no charge by BADECO in Geneva within two years of invoice date. During the warranty period, all pieces dismantled by the user will be repaired at user's expense. The guarantee excludes standard wear and tear and inappropriate use or damage caused by the buyer or a third person and defects owing to external circumstances.

We do not assume any responsibility.
Legal domicile is Geneva.
Swiss law.
Modifications reserved.

Max. speed : 18'000 rpm

